



## Document number 481675 Belimo SGA Potentiometer Installation Instructions



The Belimo SGA24 potentiometer can be field mounted to Greenheck FSD or SMD series damper supplied with Belimo FSAF24-SR(-S) acutators to allow the damper to be used to balance airflow in ducts.





<sup>\*</sup> SPDT SWITCH FIELD SUPPLIED (FOR DRIVING DAMPER FULLY OPEN)
\*\* SPDT SWITCH FIELD SUPPLIED (FOR BYPASSING THE PRIMARY THERMOSTAT)

Note: Make sure that the slider switch inside the SGA24 is set for 2-10VDC operation.

