



CONFIDENTIAL:  
DO NOT DUPLICATE OR DISTRIBUTE.  
INTERNAL USE ONLY.

## Models RV and RVE Quick Build Help Guide

### DESIGN PARAMETERS

Heating Type	QB	Cooling Type	QB	Voltage	QB	Housing	QB
None	✓	None	✓	208	✓	RV-25/RVE-40	✓
Indirect Gas	✓	Chilled Water	X	230	✓	RV-45/RVE-85	✓
Hot Water	X	Split System DX	X	460	✓	Other	X
Electric	✓	Packaged DX	X	575	X		
Air-Source Heat Pump	X	Split System DX w/ RC	X				
		Air-Source Heat Pump	X				

### COOLING

#### ENERGY RECOVERY WHEEL (RVE ONLY)

Model	Nomenclature	QB
ERC-3628C	36-30H	✓
ERC-4136C	41-30H	✓
ERC-5262C	52-30H	✓
ERC-5874C	58-30H	✓
Other Polymer Wheels		X
Aluminum Wheels		X

### HEATING

#### INDIRECT GAS HEATING

Gas Type	QB
Natural	✓
LP	X
Turndown	QB
4:1	X
High	✓
Furnace turndown is selectable on the Controls Tab.	

#### ELECTRIC HEATER

Housing	Voltage	Heater kW	QB
RV-25/ RVE-40	208	32.8	✓
	460	35	✓
		60	✓
RV-45/ RVE-85	208	32.8	✓
		57.4	✓
	460	35	✓
		60	✓
		100	✓
Other			X

### SELECTION

Housing	Exhaust/Supply Blower	Motor HP	QB	Wheel Frost Control (RVE only)	QB
RV-25/ RVE-40	PRM-450	Any	✓	Electric Preheater	X
RV-45/ RVE-85	PRM-560	Any	✓	Other	✓
Other					X

### CONTROLS

Unit Controls	QB
Heat-Cool Only Controls	X
Full Control	✓

### ACCESSORIES

Finishes	QB
Permatecor	✓
Hi-Pro Poly	X

✓ = QB Compatible

X = QB Incompatible

Note: SDRs and coil coatings are NOT allowed on Quick Build selections.